



Artikel-Nummer Article Code Numéro d'article		Artikel Article Article	Inhalt Volume (cl)	Durchmesser Diameter (mm)	Höhe Height (mm)	Gewicht Weight (g)	inch / OZ	Artikel-Nummer Article Code Numéro d'article
ESK1927		Teller tief Plate deep Assiette creuse		278	51	885	11"	
ESK1929		Pastateller Pasta plate Assiette aux pâtes		295	62	1018	11 5/8"	
ESK2122		Teller flach Plate flat Assiette plate		221	19	440	8 5/8"	
ESK2129				297	25	950	11 5/8"	
ESK2133				336	29	1235	13 1/4"	
TIM0211		Tasse stapelbar Cup stackable Tasse empilable	10	58	56	110	3 4/8 OZ	
ESK1717		Untertasse Saucer Sous-tasse		170	20	240	6 5/8"	
TIM0220		Tasse stapelbar Cup stackable Tasse empilable	20	77	63	185	7 OZ	
ESK1717		Untertasse Saucer Sous-tasse		170	20	240	6 5/8"	
TIM0030		Tasse hoch Mug Tasse haute Чашка высокая Šálek vysoký	33	77	102	290	10 4/8 OZ	
ESK1717		Untertasse Saucer Sous-tasse		170	20	240	6 5/8"	
TIM1124		Suppentasse stapelbar Cream soup cup stackable Tasse à consommé empilable	25	97	50	200	8 4/8 OZ	
TIM1133			34	103	62	240	11 4/8 OZ	
ESK1717		Untertasse Saucer Sous-tasse		170	20	240	6 5/8"	
TIM1413		Schüssel Bowl Bol	71	132	80	440	5 1/8"	
TIM1418			170	183	87	740	7 1/8"	
TIM4326		Suppenterrine o/Deckel Souptureen w/o cover Soupière sans couvercle	260	231	109	1700	87 7/8 OZ	
TIM4526		Deckel Cover Couvercle			65	580		

ESK3310		Sauciere Gravy boat Saucière	10		46	100	3 4/8 oz	
TIM3603		Gliesser ohne Henkel Creamer w/o handle Crémier sans anse	4		53	60	1 oz	
TIM3515		Milchkanne Milk pot Pot à lait	15		84	170	5 2/8 OZ	
TIM3850		Kaffeekanne o/Deckel Coffeepot w/o cover Cafetière sans couv.	53		132	440	21 1/8 OZ	
TIM3950		Deckel Cover Couvercle			29	85		
TIM3710		Kaffeekanne o/Deckel Coffeepot w/o cover Cafetière sans couv.	100		171	630	38 6/8 OZ	
TIM3960		Deckel Cover Couvercle			33	120		
TIM4160		Teekanne o/Deckel Teapot w/o cover Théière sans couv.	55		88	450	21 1/8 OZ	
TIM3960		Deckel Cover Couvercle			33	120		
TIM4302		Zuckerbol o/Deckel Sugar bowl w/o cover Sucrier sans couv. Сахарница Cukřenka	28	98	52	165	3 7/8"	
TIM4502		Deckel Cover Couvercle		104	17	90		
TIM4813		Eierbecher Egg cup Coquetier		124	19	585	5 1/8"	
TIM5001		Salzstreuer Salt shaker Salière Солонка Sypátko sól			56	55		
TIM5011		Pfefferstreuer Pepper shaker Poivrier			56	55		
TIM4608		Vase Tablevase Vase			78	215		

